




Steps to be followed to install the LogX HMI Software

1. Download all the files from download section
<http://injectsolar.com/product.html>
2. First Install LogX HMI-User.msi
3. Try to run the software after installation, if it is not opening then go for Step-4.
4. Install Pre-requisite given in website(Sr. No-2 of download section) <http://injectsolar.com/product.html>
5. Now go to C:\Program Files (x86)\INJECT SOLAR LLP\LogX HMI-User
6. Right click on db folder and go to properties
7. In Attributes uncheck Read Only
8. Go to Security Tab &
 -  Select the user which is logged in
 -  Go to edit
 -  Give full control to user & Apply Ok.
9. Now open the LogX HMI-User from desktop shortcut.

Here we go, it will work fine